


MOTOR PROGRAMMING QUICK START GUIDE

NOTE: THE SHADES' MOTORS ARE PARTIALLY CHARGED TO ENABLE PROGRAMMING. ADDITIONAL CHARGING REQUIRED AS FINAL STEP.




Get familiar with your new motor and remote control



STEP 1 Select a CHANNEL on the remote control






STEP 2 POWER ON motor and link your remote control







Click QR CODE for video Instructions

STEP 3 Set UPPER LIMIT (when shade is fully raised)



STEP 4 Set LOWER LIMIT (when shade is fully lowered)



FINAL STEP

CHARGE each motor 8 hours to fully charge battery

Congratulations! You have programmed your new motorized shade.

See the detailed instructions (included with your shade) for additional programming & operating options; for example, setting an intermediate limit, adjusting or erasing limits, programming multiple shades on a single channel, etc.