


# Vertical Blind – Wand Control Installation Instructions

## Please follow these Installation Instructions

You will need a pencil, tape measure, drill, screwdriver, pliers, and appropriate fasteners.

### Step 1: Choose the Correct Fastener



### Step 2: Bracket Installation


(Before installing, review the chart below to confirm the correct # of brackets per blind) For Inside Mount blinds with a valance Go to step 7

#### Outside Mount (Figure A)




Standard outside mount aka wall mount- To determine the the height of the top of the bracket by adding 1/2" to the blind height (including headrail) When installed, louvers will clear the floor by 1/2". Place the first bracket directly over the corner of the window with a maximum space of 30" between brackets. Adjust the bracket so the louvers clear all obstructions.

#### Inside Mount No Valance (Figure B or C) Inside Mount with a Valance see step 7



Use mounting clips to secure headrail on ceiling or inside mounts. The center of the mounting clips align with the center of the louver carrier stem. Position the screws a minimum of 2 1/4" in front of the window frame or any projection. Set mounting clips with a maximum space of 45" apart from each other. Allow a minimum of 1/2" clearance above sill or carpet.




Use the following # of Installation Brackets based on the Blind Width:

Up to 45"	46" -90"	91- 135"	136"- 191"
2	3	4	5


### Step 3: Headrail Installation

Mount the installation brackets on the headrail then snap in place, as shown below. To remove headrail, simply push the release lip up with a screwdriver.




### Step 4: Louver Installation

Push the louver up into the carrier stem, then pull slightly straight down to lock in place.




### Step 5: Test Rotation



To rotate the louvers, rotate the wand in the direction you want the louvers rotated. This step will align all of the louvers.

### Step 6: Test Traverse



Alternatively To traverse the louvers, rotate the louvers to the open position then push or pull the wand to open (stack louvers) or close (unstack louvers) the blind.

**Caution: Do not traverse the blind with the louvers in the closed position.**

# Vertical Blind– Wand Control Installation Instructions

## Step 7: Valance Installation

For inside or ceiling mounts (figure A), install the headrail bracket clip mounting screw through the valance as shown. Make sure louvers do not touch the valance.

For outside mounts (figure B), the dustcover of the valance slides under the protruding clip on the top of the mounting brackets.

Figure A





Figure B



## Valance Corners and Returns (figure C)

Outside mount valances are available with Square or Round Corner and returns.

For **square corner valances (figure D)**, the valance insert will arrive inserted into the front of the valance and in the returns. Simply slide the corners onto the ends of the valance. Then slide the returns into other end of the corner.

For **rounded corner valances (figure D)**, the valance insert is a continuous piece and will require assembly. Locate the valance insert, round corners and returns. Grasp the middle of the valance insert, squeezing slightly as you slide it under the top and bottom channel on the face of the valance. Continuous to slide the insert into the face of the valance. Then focusing on one end at a time, attach the corner and return. You may need to trim any excess valance material with heavy-duty scissors.

\*\*If you ordered PVC vanes, the valance insert will be shipped rolled up. If you ordered fabric verticals, the insert will be rolled up with the PVC vanes.

Figure C





Figure D



## Operating Instructions

### Wand Control

To rotate the louvers, rotate the wand in the direction you want the louvers rotated. To traverse the louvers, rotate the louvers to the open position. Then, push or pull the wand to open (*stack louvers*) or close (*unstack louvers*) the blind. If louvers are installed with the front of the louver facing the wand, the wand will be in front of the louvers when the blind is rotated closed. If the louvers are installed with the back of the louver facing the wand, the wand will be in back of the louvers when the blind is rotated closed.

If louvers become tangled or have moved out of alignment with use, re-adjustment is simple. With your hand, gently adjust the louvers so they are all facing the same direction. Make certain that the louvers are overlapping each other in the correct direction. Then rotate the wand until you hear a grinding sound. Give the wand a few additional gentle turns. This grinding noise is the louver carriers re-aligning themselves. Now rotate the wand in the opposite direction several times. Continue to rotate it a few times once the loud clicking noise starts. After a few turns, all of the vanes should be aligned correctly.